

## **Wet Application Instructions**

**Soap and Water Mix:** Using a 32 oz water bottle- Mix 2 corn kernel size drops of Johnsons Baby shampoo (yellow lid, clear bottle) and shake. That's all you need as your slip mix, if too much it will prevent permanent adhesion of the graphics to the surface.

**Graphics with transfer tape:** For the panels with transfer tape, it is the same process except we recommend you wait to pull off the top transfer tape to allow the adhesive to tack (5 min or so). When peeling the transfer tape, pull it off the design slowly and peel it back over top of itself, do not pull it straight up in the air. This will help prevent your pulling the graphic off of the surface. Some elements may have fine points so use caution when doing so.

Watch video: [https://www.youtube.com/watch?v=703\\_YDV5S7k](https://www.youtube.com/watch?v=703_YDV5S7k)

## **Wet Application Instructions for graphics without transfer tape:**

Watch video: <https://www.youtube.com/watch?v=cFLga2jUfcE&t=14s>

<https://www.youtube.com/watch?v=1Nwaonw-850>

**Graphics without transfer tape-** for the panels and individual elements that do not have transfer tape, be sure you wet your hands before pulling the design off the paper. This will help prevent your finger prints from marking the adhesive during transfer. (after you have done your final prep with the 70% alcohol and paper towel.) Spray the surface of the bike and the adhesive side of the design before transfer. Then you can place it and move it around if needed. Squeegee from the center of the design to the outside using gentle overlapping strokes. It's best to leave the bike in the sun (or warm with hair dryer) so that the water will breathe out to take its permanent bond. This will happen over time. It's helpful to leave the bike in the sun as well.