

RT 15" 12 Spoke Wheel Kit Installation Instructions

1. For best results, we recommend you remove the wheel from the Spyder.
2. The temperature of the wheel and atmosphere should be at least 65F.
3. Thoroughly wash and clean wheels using simple green and hot water.
4. Final surface prep once the wheel is completely dry--70% Rubbing Alcohol with kitchen paper towel. *Do not use shop towels.*
 - * Making a straight line down the center of each piece on the transfer tape with a straight edge would be helpful for alignment.
5. Laying the wheel facing up, remove one of the decals from the supplied backing.
6. Align in its proper position, being sure that the decal is centered where it is to be applied.
7. Tack from the center hub and work your way to the outside of the wheel lightly pressing down the decal work from center to outsides. Match edges of each piece parallel together.
 - Use the supplied squeegee to install.
8. **THIS IS VERY IMPORTANT!! DO NOT STRETCH THE DECAL. IT IS MADE TO FIT AT THE SIZE SUPPLIED.**
9. Re wipe each spoke prior to completing steps 6-8.
10. If you have any air bubbles, try pressing them with your squeegee to the outside or puncture with a safety pin to release air.
11. Repeat process to finish the wheel. Once complete, use hair dryer to warm the vinyl. Do not wash for 1 week. Pressure washing is not recommended.



WrapMySpyder
.com